



## Installation Instructions

For Kodlin NXL Floorboards for HD Touring models- K73253

1. Remove your old floorboards.
2. Layout your NXL Floorboards, four mounts and hardware. See picture #1
3. Match the mounts with the bolt hole patterns on bottom of the Trackboards.
4. Using medium strength thread locker on all bolts install three bolts in each mount. After you have started all the bolts torque each one to 80-90 In/lbs. See picture #2
5. Install Trackboards using supplied hardware. Apply medium strength thread locker to bolts, install nuts and torque to 60-80 in/lbs.



#1



#2

**For the latest install guides, video's, FAQ's. and Tech-Tip's scan QR code!**



Revision Date: 3/11/2024

[www.kodlinusa.com](http://www.kodlinusa.com)