



Installation Instructions

for Kodlin NXL Mini Boards - K73254

Note: Must have a Kodlin Splined Peg Adapter installed to use this product

1. Remove old pegs and replace them with peg adapters for your setup.
2. Bolt has thread locker on it already. Install bolt through NXL Mini Board and then into peg adapter. Align peg as needed then firmly tighten bolt.
3. Check for proper alignment and if not correct, realign. Check again and once properly aligned torque bolt to 15-20 ft/lbs.



#1



#2

For the latest install guides, video's, FAQ's. and Tech-Tip's scan QR code!



Revision Date: 3/11/2024

www.kodlinusa.com