



## Installation Instructions

For Brake Master Cylinder Cover for VVT Style Touring – KUS25855-KUS25856

A FACTORY SERVICE MANUAL WILL BE HELPFUL IN PERFORMING THIS INSTALLATION. DO NOT ATTEMPT TO PERFORM THIS INSTALLATION IF YOU ARE NOT CONFIDENT IN YOUR ABILITY TO COMPLETE ALL OF THE STEPS IN THE PROCEDURE; CONSULT A TRAINED TECHNICIAN. IMPROPER INSTALLATION COULD RESULT IN SERIOUS INJURY OR DEATH.

1. Situate the motorcycle and the handlebars so that the front brake master cylinder is sitting level to prevent the brake fluid from running down the sides.

**Warning: If DOT 4 brake fluid contacts painted surfaces, IMMEDIATELY flush area with clear water**

2. Remove the three screws and cover along with the gasket. Wipe down the gasket for reuse later.
3. Clean all edges and install gasket and cover.
4. Carefully install provided screws and ensure the cover is tightened up against the gasket and housing.
5. Hand tighten screws and wipe away any seepage around edges.
6. Verify proper brake operation prior to riding.



**NOTE: No warranty coverage is provided by Kodlin that is due to improper installation or lack of maintenance. Periodic maintenance and inspection are required. It is the installer's responsibility to ensure that all the fasteners are tightened before operation of the motorcycle. We recommend following the Mfg.'s torque specs.**

For the latest install guides, video's, FAQ's. and Tech-Tip's scan QR code!



Revision Date: 1/14/2025

[www.kodlinusa.com](http://www.kodlinusa.com)