



## Installation Instructions

For

Kodlin Water Reservoir Cover for 23.5-up VVT Style Touring- K25413/K25414

A FACTORY SERVICE MANUAL WILL BE HELPFUL IN PERFORMING THIS INSTALLATION. DO NOT ATTEMPT TO PERFORM THIS INSTALLATION IF YOU ARE NOT CONFIDENT IN YOUR ABILITY TO COMPLETE ALL OF THE STEPS IN THE PROCEDURE; CONSULT A TRAINED TECHNICIAN. IMPROPER INSTALLATION COULD RESULT IN SERIOUS INJURY OR DEATH.

**Note: Use a small amount of medium strength thread locker on all set screws.**

1. Using an allen wrench install the reservoir cap using the two small allen set screws provided. Align as shown in picture #1.
2. Start the lower two set screws but do not screw into the inner side too far or cover won't slide on.
3. Carefully pull the water reservoir away from the plastic holder.

**Warning: Do not screw the outside end of the set screw past the surface of the cover or you risk damaging plastic reservoir!**

4. Slide the cover down over the reservoir until it rest on the cap.
5. If there is a little resistance to the cover easily sliding on, slightly loosen the set screws for additional clearance until cover is all the way down.
6. Align cover with the mounting bracket and push the cover and reservoir onto the mounting bracket. Align again for clearance with bracket and tighten the two lower set screws. Do not go in farther than flush with the surface of the cover. See picture #2.
7. The cover should be snugly on the reservoir.
8. Make sure the reservoir's bottom hose grommet is correctly in place on the holder.



#1



#2



#3

**NOTE: No warranty coverage is provided by Kodlin that is due to improper installation or lack of maintenance. Periodic maintenance and inspection are required. It is the installer's responsibility to ensure that all the fasteners are tightened before operation of the motorcycle. We recommend following the Mfg.'s torque specs.**

**For the latest install guides, video's, FAQ's. and Tech-Tip's scan QR code!**



Revision Date: 1/15/2025

[www.kodlinusa.com](http://www.kodlinusa.com)