



Installation Instructions for

Kodlin Custom FatBoy and Breakout Seats K59660, K59661-L and K59662-S

These seats have been designed to use a hidden rear mount setup. On the bottom back of the seat is a small $\frac{1}{4}$ " button head bolt. See picture #1. This bolt is used to mount rear of the seat to the fender. Install seat in typical fashion by inserting the front tab into tank bracket then insert button head bolt. The bolt will go in from under the fender and screw into the seat to pull it down flush with fender. We suggest fitting the seat and drilling the fender hole before final painting of the fender.



Picture #1

NOTE: For those not familiar locating hole position on the fender. You can put tape on fender in area where bolt should line up. Unscrew bolt about $\frac{1}{4}$ " - $\frac{3}{8}$ " and fit seat back into position on bike. Make sure to fit seat up tight against tank and make sure it is aligned with fender then carefully press down on rear of seat as it sits in the position you want it. The bolt should make an indent in the tape. Be careful not to move seat around or push more than once or you may get several marks making it more difficult to determine where to drill. Reapply tape and repeat these steps until you are confident of the hole location. Drill $\frac{1}{4}$ " hole as needed being careful not to drill into your tire.

NOTE: No warranty coverage is provided by Kodlin that is due to improper installation or lack of maintenance. Periodic maintenance and inspection are required. It is the installer's responsibility to ensure that all the fasteners are tightened before operation of the motorcycle.

For the latest install guides, video's, FAQ's. and Tech-Tip's scan QR code!



Revision Date: 12/12/2022

www.kodlinusa.com