



Installation Instructions

For Kodlin Rear LED Wiring Harness for KUS20302, 3-1 VVT Style License Plate Kit -
KUS11700

DO NOT ATTEMPT TO PERFORM THIS INSTALLATION IF YOU ARE NOT CONFIDENT IN YOUR ABILITY TO COMPLETE ALL OF THE STEPS IN THE PROCEDURE; CONSULT A TRAINED TECHNICIAN. IMPROPER INSTALLATION COULD RESULT IN SERIOUS INJURY OR DEATH.

1. Remove left and right side saddlebags.
2. Unplug the OEM harness from the rear light assemblies by pushing down on the tab and gently pulling out.
3. Using the longer of the two harnesses connect one end of the short tee to existing harness and the other end to the rear light assembly.
4. Run the longer length of the harness tee downward under the fender then around up to top of fender support bar at gap on left side between fender and bar. Continue down through the gap out bottom then continue to right side.
5. Connect the short harness in the same fashion as the right side. Go down to the right side of fender support bar, this time going down to bottom of bar then up through gap.
6. After following the instructions for the 3-1 VVT style license plate kit KUS20302 connect both connectors to license frame connectors. Make sure to connect the longer left side harness to the left side connector from the frame.
7. Finish installing the plate kit.
8. Make sure to route wires in a way to keep away from tire to prevent rubbing of the tire against wires.
9. Zip tie loose wire as needed.

NOTE: No warranty coverage is provided by Kodlin that is due to improper installation or lack of maintenance. Periodic maintenance and inspection are required. It is the installer's responsibility to ensure that all the fasteners are tightened before operation of the motorcycle. We recommend following the Mfg.'s torque specs.

For the latest install guides, videos, FAQs and Tech-Tip's scan QR code!



Revision Date: 5/6/2025

www.kodlinusa.com