



Tech-Tip for installing Road Glide Front Elypse Turn Signals K68459 and K68487

This tech-Tip addresses two common issues customers seem to have when installing these lights.

- Pinching the LED wires in bolt hole when reinstalling the mounting bolt.
- Overtightening mounting bolt and pinching wires between LED lights and light standoff.

By following this suggestion, you can eliminate both from becoming a problem.

1. Simply drill a small 1/8" hole in the standoff to route the LED wires forward of the bolt hole to help keep the wires out of the way when installing and tightening the mounting bolt. This will eliminate the need to route wires around bolt hole to the rearward wire access on the standoff and removes the threat of pinching the wires.

